



FEATURES:

Basic Features

- H.264 Live View, Recording and Playback
- 128 Channel Multi-live View
- 32 Channel Recording
- NVR Recorded Video Archive
- Event Trigger, Response and Notification
- ONVIF Protocol Support
- Remote Viewer (Client)
- Export File with Multi Formats


FEATURES:

Advanced Functions

- Customized Layout
- H.265 Support
- Unlimited Camera Connection
- Highlight Browser Mode
- Hardware / Software Decoding Support
- HTTP Streaming Support
- Fisheye Dewarping
- E-Map
- Bandwidth Management
- Synchronized playback
- Event Audio Notification
- Multi-tab Live View Page Layout
- Covert Account Setting
- Customized Layout
- User-Friendly Modification
- Up to 128 Channel Live at Same Time
- High Light Browser Mode

ST-Video Management Software

SYSTEM DIAGRAM







ST-Video Management Software

GENERAL			
Maximum Number of NVR			
Maximum Number of Clients	8 viewers / 128CH streaming connection(concurrent)		
Maximum Number of Cameras	Unlimited		
Free License	32 CH recording, 128 CH live view display		
Compression	H.264, H.265		
LIVE VIEW			
Display Mode	1, 4, 9, 16, 25, 36, 49, 64, 132, Browser, Custom		
View Manager	A interface to define layouts and pre-set cameras in multiple view mode		
View Patrol	Able to switch between different view pages and devices		
Layout Manager	A interface to modify display layout, position and the size of live view of camera within layout		
Digital Zoom	Zoom in/ Zoom out digitally by mouse scroll wheel		
Snapshot	Instant snapshot upon mouse click		
Event Notification	Alarm, Motion detection, Connection loss/ auto reconnect between VMS and NVR/camera		
Bandwidth Management	Live view with stream 1 in full screen mode or stream 2 in multi-view screen mode (Bitrate adjustable)		
Camera Management	Camera control, image setup, camera video format, IR/Exposure setup, Camera information		
E-MAP			
Layout	Area maps with camera icons, small live view screen; alarm trigger, event trigger		
Setup	Google map positioning; E-Map image upload; camera positioning; camera vision angle and direction		
PTZ			
	PTZ		
Control	PTZ Pan, tilt, zoom control; focus, exposure adjustment		
Control Preset Points and Tours			
	Pan, tilt, zoom control; focus, exposure adjustment		
Preset Points and Tours	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes		
Preset Points and Tours Joytick	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec DEVICE MANAGEMENT		
Preset Points and Tours Joytick	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec		
Preset Points and Tours Joytick Default protocol	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec DEVICE MANAGEMENT		
Preset Points and Tours Joytick Default protocol Device Search	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec DEVICE MANAGEMENT Auto connect/ Auto scan / Manual add NVR or Camera Model name, IP address, MAC address, type, protocol,		
Preset Points and Tours Joytick Default protocol Device Search Device Information	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec DEVICE MANAGEMENT Auto connect/ Auto scan / Manual add NVR or Camera Model name, IP address, MAC address, type, protocol, streaming port, port, video snapshot		
Preset Points and Tours Joytick Default protocol Device Search Device Information	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec DEVICE MANAGEMENT Auto connect/ Auto scan / Manual add NVR or Camera Model name, IP address, MAC address, type, protocol, streaming port, port, video snapshot IPCAM, NVR, DVR, VSS; ONVIF		
Preset Points and Tours Joytick Default protocol Device Search Device Information Search Filter	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec DEVICE MANAGEMENT Auto connect/ Auto scan / Manual add NVR or Camera Model name, IP address, MAC address, type, protocol, streaming port, port, video snapshot IPCAM, NVR, DVR, VSS; ONVIF PLAYBACK & EXPORT Search video recording by time, event, channel from multiple cameras/ NVRs		
Preset Points and Tours Joytick Default protocol Device Search Device Information Search Filter Recording Search	Pan, tilt, zoom control; focus, exposure adjustment Set/ Activate Preset points; Set/ Activate tour routes USB based Joystick support (CH Flightstick Pro 4-Button integrated) SensorTec DEVICE MANAGEMENT Auto connect/ Auto scan / Manual add NVR or Camera Model name, IP address, MAC address, type, protocol, streaming port, port, video snapshot IPCAM, NVR, DVR, VSS; ONVIF PLAYBACK & EXPORT Search video recording by time, event, channel from multiple cameras/ NVRs Instant view, snapshot and export Continuous forward and backward with		







ST-Video Management Software

Digital Zoom	Zoom in/ Zoom out digitally by mouse scroll wheel		
VIdeo Export	Export Video clips with AVI, RAW, MP4, MKV, MOV; signature supported		
EVENT MANAGEMENT			
Event Source	Mmuoltiiopnledceatmecetrioans/, NAlVaRrms , Video loss		
Event Trigger	Video motion detection, Alarm, Video loss		
Event Response	Instantly Record video, audio notification, full screen pop-out with live video, email notification		
Smart Search	Smart search list for recorded videos by video motion detection/ alarm/ video loss		
	SYSTEM		
Video decoding	Hardware/ Software		
Permission Management	Unlimited number of users, Active Directly, customized permissions for different user Including covert cameras/ NVRs, device management, playback & export		
Language	Multiple language support		
Operation Log Management	Recorded list of user operation, IPCAM event, NVR event		
System status	Instant view of CPU usage, RAM, HDD valid space, Network status		
Setting Import/ Export	Possibility to import or export setting packs for convenient VMS setting management		
REMOTE ACCESS			
PC Client Software	VMS software with Live view, Playback, E-map, setup		
PC Web Browser	Microsoft Internet Explorer 11 with 16CH display layout		
REMOTE ACCESS	MINIMUM	RECOMMENDED	
CPU	Intel CPU Core i3-4150 3.5GHz	Intel CPU Core i5-4590S 3.2GHz	
RAM	2x2 GB	2x4 GB	
Graphics (e)	Intel HD Graphics 4400	Intel HD Graphics 4600	
IP Camera Input	64 CH live view with 16 CH recording	128 CH live view with 32 CH recording	
Hard Drive Space	500MB	500MB	
os	x64 Windows 7 Ultimate, Windows 7 Enterprise, Windows 7 Professional, Windows 7 Premium, Windows 7 Basic x64 Windows 8 Enterprise, Windows 8 Pro, Windows 8		
Software	NET 4.0 Framework		

